



Store & Go Dump Truck™




Parent's Guide

This guide contains important information. Please keep it for future reference.

INTRODUCTION

Thank you for purchasing the **LeapBuilders® Store & Go Dump Truck™** set. This interactive truck-building set comes with 10 double-sided learning blocks and three building pieces, including an electronic Smart Star™ cube. Insert the learning blocks into the interactive Smart Star™ cube to learn about shapes, vocabulary words and colors. Drop the blocks into the top of the truck for fun sounds and music.



INCLUDED IN THIS PACKAGE

One Interactive Smart Star[™] Cube



· One Bucket



· One Base With Wheels



• 10 Double-Sided Learning Blocks



· One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cord and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this parent's guide as it contains important information.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE:

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the packaging locks:



- ① Rotate the packaging lock 90 degrees counterclockwise.
- ② Pull out the packaging lock and discard.

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned OFF.
- Locate the battery cover and use a screwdriver to loosen the screw and open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- 4. Install 2 new AAA batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)



5. Replace the battery cover and tighten the screw to secure.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- · Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- · Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- · Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas utiliser des piles ou des accumulateurs endommagés.
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -).
- Enlever les piles ou les accumulateurs usagés du jouet.
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Ne les jeter ni au feu ni dans la nature.
- Ne pas tenter de recharger des piles non rechargeables.
- Enlever les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.

PRODUCT FEATURES

1. On/Off/Volume Control Switch

To turn the unit On, slide the On/Off/Volume Control Switch to the Low Volume (1) or High Volume (1) position. To turn the unit Off, slide the On/Off/Volume Control Switch to the Off (2) position.



2. Music Button

Press the **Music Button** to play four learning songs and three musical tunes.



3. Question Button

Press the **Question Button** to hear learning questions and inspirational building ideas.



4. Automatic Shut Off

To preserve battery life, the **LeapBuilders® Store & Go Dump Truck™** set will automatically shut off after approximately 100 seconds without input. The unit can be turned on again by pressing any button, inserting a **Learning Block** into the **Smart Star™ Cube** or dropping a block into the **Block Chute**. The motion sensor will not turn the unit back on.

Note: This product is in Try-Me mode in the packaging. After opening the package, turn the product off and on again to proceed with normal play. If the unit powers down while playing, please install a new set of batteries.

ACTIVITIES

1. Music Button

Press the **Music Button** to hear three short tunes and four learning songs about building and construction. The lights will flash with the sounds.



2. Question Button

Press the **Question Button** to hear interactive questions and short tunes. The lights will flash with the sounds.



3. Smart Star™ Cube

Insert the double-sided **Learning Blocks** into the interactive **Smart Star™ Cube** to learn about shapes, vocabulary words and colors. The lights will flash with the sounds.



4. Rolling Fun

With the interactive **Smart Star**™ **Cube** attached to the **Wheel Base**, roll the truck to hear fun sound effects, phrases and short tunes.



5. Block Chute

Push the blocks through the **Block Chute** and into the bucket to hear fun sounds and music. The lights will flash with the sounds.



6. Horn Button

Press the **Horn Button** to hear fun truck sounds and phrases. The lights will flash with the sounds.



7. Mix and Match

For added fun, the **LeapBuilders® Store & Go Dump Truck™** set interacts with the **Learning Blocks** from other **LeapBuilders®** sets. Simply put a **Learning Block** from another **LeapBuilders®** set into the interactive **Smart Star™ Cube** to see flashing lights and hear learning phrases and short tunes (additional sets sold separately). Please note, blocks from sets in different languages have unique audio responses and cannot be used interchangeably.

SING-ALONG SONG LYRICS

Song 1

Moving blocks is so much fun, With LeapBuilders. Load me up, let's get it done! We're learning with LeapBuilders now, yeah!

Song 2

Let's drive around And make something great! Let's drive around.

Song 3

I'm a dump truck and I work all day, Hauling these blocks all around! Red ones, blue ones, yellow and green ones, Colors all around!

Song 4

Dump truck! Finding shapes and then we're movin'. Dump truck!

Circles, squares, we keep on groovin'.

We're stacking them high, and building with our dump truck! We keep on moving and building with our dump truck!

CARE & MAINTENANCE

- Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit will now be ready to use again.
- If the unit still does not work, install a brand new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at 1-800-701-5327 in the U.S. or email support@ leapfrog.com. Creating and developing LeapFrog® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

Environmental Phenomena

The unit may malfunction if subjected to radio-frequency interference. It should revert to normal operation when the interference stops. If not, it may become necessary to turn the power **OFF** and back **ON**, or remove and reinstall the batteries. In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

Impact de l'environnement

Une défaillance de fonctionnement de l'appareil peut survenir s'il est sujet à des interférences avec les fréquences radioélectriques. Le fonctionnement normal de l'appareil devrait reprendre avec l'arrêt des interférences. Si ce n'est pas le cas, il peut s'avérer nécessaire d'éteindre et rallumer l'appareil ou de retirer et réinstaller les piles. Dans l'éventualité peu probable d'une décharge électrostatique, un mauvais fonctionnement et une perte de mémoire de l'appareil peuvent se produire. L'utilisateur doit alors retirer et réinstaller les piles pour réinitialiser l'appareil.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

Trade Name: LeapFrog® Model: 6097

Product Name: LeapBuilders® Store & Go Dump Truck™

Responsible Party: LeapFrog Enterprises, Inc. Address: 6401 Hollis Street, Suite 100,

Emeryville, CA 94608

Website: leapfrog.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-3 (B)/NMB-3(B)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Read our complete warranty policy online at leapfrog.com/warranty.





Visit our website for more information about our products, downloads, resources and more.

leapfrog.com

LeapFrog Enterprises, Inc. A subsidiary of VTech Holdings Limited. TM & © 2019 LeapFrog Enterprises, Inc. All rights reserved. 91-003777-000 ©